

Kelba (Australia) Pty Ltd

Tel: Int 61 2 9476 4544 Web: www.kelba.com Email: Kelba@bigpond.net.au

PA8101S Manual ~ TABLE OF CONTENTS

Chapter 1: Introduction to the PA8101S Indicator(1)

Chapter 2: Panel and Connectors(1)

Chapter 3: Function Keys and Annunciators(3)

Chapter 4: Menus(4)

Chapter 5: Setup “F” Menu(5)

Chapter 6: User “A” Menu(8)

Chapter 7: Operation(10)

Chapter 8: RS-232 Communication(13)

Chapter 9: Specifications(14)

Appendix A: Print Ticket Mode.....(14)

Appendix B: Units Conversion Chart(15)

Appendix C: Displayed Error Codes.....(15)

Appendix D: Minimum Recommended Span Gain Table(16)

Chapter 1: Introduction to the PA8101S weight indicator

PA8101S Weight Indicator is a general purpose, industrial grade weight indicator with piece counting operation, custom units, peak hold, and percent mode and weight test features.

Chapter 2: Panel and Connectors

2.1 Front panel see Fig. 1, connectors see Fig. 2.




Fig. 1




Fig. 2

2.1.1 Front panel

- a. 0.8 inch 6 digits LED display.
- b. 8 LED's legends.
- c. 5 function keys.

2.1.2 Connectors

COM1: Load cell connector

COM2: RS 232C connector, or RS 485 connector, or 20mA current loop connector for remote display.

COM3: Power connector

2.2 Wiring

2.2.1 Wiring for COM1 load cell connector sees Fig. 3.

Pin No.	Color	Wire Name
E1	Red	Excitation111
E2	Black	Excitation111
S1	Green	Signal111
S2	White	Signal111

Fig. 3

2.2.1 Wiring for RS 232C, or RS 485, or current loop connector see Fig. 4.

Pin Nos.	Wire Name
CL1	Current loop output (1)
CL2	Current loop output (1)
B(1)	B(1)
A(1)	A(1)
GND	COM
RXD	RXD
TXD	TXD

Fig. 4

Chapter 3: Function Keys and Annunciator

3.1 Function Keys

[UNITS] — This key toggles the indicator among the available weight units in the Setup “F” menu. The unit will be changed between F9 and F10 if you press this key.

1. The indicator will be in Piece Counting mode when F12□2, and the “PCS” annunciator will be on at this time if you press the **[UNITS]** key.
2. The indicator will be in Peak Hold mode when F12□3 if you press the **[UNITS]** key.
3. The indicator will be in Percent Weighing mode when F12□4, and the “PCS” annunciator will be on at this time if you press the **[UNITS]** key.
4. The indicator will be in Animal weight mode when F12□6, and there is a “=” sign on the left if you press the **[UNITS]** key.

[ZERO] — This key sets the indicator to display zero provided the following conditions are met:

1. The displayed weight is with the zero reset range.
2. The scale is not in motion.
3. The scale is not in overload.

[NET/GROSS]— This key toggles the indicator between Gross weight and Net weight only if a Tare has been established.

[TARE] — This key is used to establish a Tare provided the following conditions are met:

1. The scale is not at or below Gross zero.
2. The scale is not in motion.
3. The scale is not in overload.

[Print] — This key is used to send weight information out to the Printer provided the following conditions are met.

1. The scale is not in motion.
2. The scale is not in overload

3. 2 Annunciators

GROSS: Denotes that the indicator is displaying gross weight.

NET: Denotes that the indicator is displaying net weight.

TARE: Indicates that a tare weight has been established in the system.

ZERO: This light is active whenever the displayed weight is zero.

lb: Indicates that the unit of the displayed weight is “lb”.

kg: Indicates that the unit of the displayed weight is “kg”.

PCS: If the indicator is in More Units mode, after your pressing the **[UNITS]** key,

that the annunciator is on indicates that the unit is not “kg” and “lb” if the unit you choice is not “lb” and “kg”.

- a. The indicator will be in Piece Counting mode when F12□2, and the “PCS” annunciator will be on at this time if you press the [UNITS] key.
- b. The indicator will be in Peak Hold mode when F12□3, and the “PCS” annunciator will be on at this time if you press the [UNITS] key.
- c. The indicator will be in Percent Weighing mode when F12□4, and the “PCS” annunciator will be on at this time if you press the [UNITS] key.

STABLE: Indicates that the scale is stable.

Chapter 4: Menus

4. 1 The indicator contains two main setup menus: The Setup (“F”) menu which configure the indicator to your weight platform and the User (“A”) menu which configures the serial communication port and enables some user options. The Setup and User menus consist of several menu selections, each with its own sub-menu of choices.

4. 2 Entering the Setup Menu.

- a. Power off the indicator by unplugging the power source.
- b. Remove the back cover and locate jumper J1, power on the indicator by plugging the power source. The indicator shows “F 1” to indicate that you are in Setup Menu mode.

4. 3 Exit the setup menu

Put into the jumper J1 switch, and the indicator will enter into the weighing mode after initialization.

4.4 Definition of the keys in the menu mode


[↑]□ Entering to the main menu.

[↓]□ Entering to sub-menu from main menu and scroll down the flashing digit 1 from 1 to 9 by press this key at setting the value in sub-menu.

[→]□ Entering to right menu in equal class and scroll up the flashing digit 1 from 1 to 9 by press this key at setting the value in sub-menu.

[←]□ Entering to left menu in equal class and change the flashing digit from higher to lower.

[set]□ Accept displayed data of a selection and return to main menu.



Chapter 5: Setup “F” Menu

5.1 Setup Menu Chart




Fig. 4

5. 2 Setup Menu Description

NAME/CODE	DESCRIPTION	CODE/VALUE
F1 Full Scale	Full Scale <input type="checkbox"/> Graduation <input checked="" type="checkbox"/> Division (See Appendix D)	500, 1000, 1500, 2000, 2500, 3000, 4000, 5000, 6000, 8000, 10000 √, 12000, 15000, 20000, 25000, 30000, 40000, 50000, 60000, 80000, 100000, 120000, 150000, 200000, 250000, 300000, 400000, 500000
F2 Division	Minimum difference between two weighing readings	1 √, 2, 5, 10, 20, 50
F3 Decimal Pt.	Determines location of the decimal point.	0 √, 0.0, 0.00, 0.000, 0.0000
F4 Overload Limit	Selects the desired formula which determines the point at which the indicator shows overload. All selections are based on the primary unit.	FS+0d FS+2% FS+1d FS+9d √
F5 Zero Track Band	Selects the range within the scale will automatically zero. Note that the scale must be in standstill to automatically zero. Selections are in Display Divisions.	0d 0.5d √ 1d 3d 5d
F6 Zero Range	Selects the range within the scale may be zeroed. Note that the indicator must be in standstill to zero the scale	1 1.9%FS 2 100%FS √
F7 Motion Band	Sets the level at which motion is detected by comparing the present display update with the previous one. If motion is not detected for 0.5 seconds of more, scale is in standstill and can process a Print or Zero command. Maximum value varies depending on local regulations	1d √ 3d 5d 10d
F8 Digital Filter	The higher the filter number, the greater the stability but the slower the response time.	L M √ H
F9 Calib. Unit	Selects the primary base unit to be used in the calibration process. Also the default unit for normal operation. “1”= t “2”= kg “3”= g “4”= lb “5”=oz	1 2 √ 3 4 5
F10 Auxiliary Units	Press the [UNITS] key to toggle the unit between calibration units and auxiliary units in weighing mode. “1”= off “2”= t “3”= kg “4”= g “5”= lb “6”= oz “7”= KN “8”= lb:oz	1 √ 2 3 4 5 6 7 8
F11 Serial Connectors	“1”= RS <input type="checkbox"/> 232C or RS <input type="checkbox"/> 485 serial connector or 20mA current loop output for remote display. “2”= Serial connector for printing “3”= Serial connector for printing automatically	1 √ 2 3
F12 Weighing Mode	“1” = Normal weighing mode “2” = Piece Counting “3” = Peak Hold “4” = Percent mode “5” = Weight testing (overload or too light) “6” = Animal weight mode	1 √ 2 3 4 5 6
F13 Time and Date Selected	“0” = Print with time and date “1” = Print without time and date	0 √ 1

NAME/CODE	DESCRIPTION	CODE/VALUE
F15 Zero Calibration	See in Form 5	
F16 Span Calibration	See in Form 5	
F17 Manual Zero Calibration	See in Form 5	
F18 Manual Span Calibration	See in Form 5	

Remark: Factory-set defaults are shown in bold with a “√”.

5.3 Calibration for the scale (Table 5)

STEP	NAME	DISPLAY	OPERATION
1	Zero Calibration (F15)	XXXXXX	Display internal codes at zero, press the [SET] key to memory the zero calibration value after the scale is stable and empty. Then return to F16 waiting for Span Calibration.
2	Span Calibration (F16)	XXXXXX	Display original weight value, you can enter new value using [←] and [→] keys, return to F16 after pressing the [SET] key when the weight is equal with the displaying value and the scale is stable. The indicator will display the correct value by pressing the [↓] key, please re-calibrate if it is not correct, it will return to F16 automatically after calibrating successfully, it will also display the error code if not success and return to F16 after 3 seconds, please re-calibrate after checking.
3	Manual Zero Calib. (F17)	XXXXXX	Display zero calibration value. You can also enter the value using [←] and [→] keys to check and amend the zero calibration value.
4	Manual Span Calib. (F18)	XXXXXX	Display span calibration value. You can also enter the value using [←] and [→] keys to check and amend the span calibration value.

Note: The weight value of span calibration is 20%F.S. at least. Zero calibration value and span calibration value can be checked in F17 and F18 after being calibrated successfully. Please fill the calibration data in the following form to prevent data missing in an accident. You can key-in the data without re-calibration.

ID NO.	Zero Calib. Value (F17)	Span Calib. Value (F18)

Chapter 6: User “A” Menu

6.1 USER MENU CHART




Fig. 5

6.2 User Menu Description

NAME/CODE	DESCRIPTION	CODE/VALUE
-----------	-------------	------------

A1 Baud Rate	Selects the baud rate for data transmission through both serial ports	1200 2400 4800 √ 9600
A2 Communication Mode	“C” = Continuous mode “D” = Command mode	C √ D
A3 Data Bits and Parity	Selects the number of data bits and parity of serial transmission. 8n□8 data bits with no parity bits and one stop bit 7O□7 data bits with odd parity bit and one stop bit 7E□7 data bits with even parity bit and one stop bit 7n□7 data bits with no parity bit and two stop bit	8n √ 7O 7E 7n
A4 Print Mode	“0” = Print “GROSS NET TARE” “1” = Print “Displayed weight”	0 √ 1
A5 ID No. Enable	“0” = Disable the ID No. “1” = Enable the ID No.	0 √ 1
A6 ID No. Entry	you can enter new time using the [←] and [→] keys and press [SET] key to confirm. Invalid when A5=0.	0~999999 123456 √
A7 No.of Line Feeds	Actuates the function that allows entry of the desired number of line feeds to be printed in Print Ticket Mode.	0~99 3 √
A8 Time Format	“0” = 12 Hr (Please add “80” if you enter the time in the afternoon. For example, if the time is 2:00 PM, your entering the time is 82) “1” = 24 Hr	0 √ 1
A9 Date Format	“0” = mm/dd/yy “1” = dd/mm/yy	0 √ 1
A10 Time Entry	Display original time, you can enter new time using the [←] and [→] keys and press [SET] key to confirm.	
A11 Date Entry	Display original date, you can enter new date using the [←] and [→] keys and press [SET] key to confirm.	
A12 Lower Limit	This is to can test the lower limit of weight, you can enter the lower limit value using the [←] and [→] keys and press [SET] key to confirm.	
A13 Peak Hold Entry (Upper Limit)	Peak hold appears when F12□2, and the peak hold value should less or equal to 100%F.S., you can enter the peak hold value using the [←] and [→] keys, then press the [SET] key to confirm. The indicator can test the upper limit of weight when F12 □5, and upper limit also need less or equal to 100%F.S., also you can enter the upper limit value using the [←] and [→] keys and press the [SET] key to confirm.	
A14 KN Unit Entry	Units can be changed between KN and kg, you can enter a 6-digit number using the [←] and [→] keys and press the [SET] key to confirm.	
A15 Total Selected	“0” = Disable the Total. “1” = Enable the Total.	0 1

Remark: Factory-set defaults are shown in bold with a “√”.

Chapter 7: Operation

7.1 Weight operation

1. Select weighing mode (F12□1)

2. Pressing [UNITS] key until it appears the unit you want.
3. If you need, press the [ZERO] key to zero out the displayed value.
4. Press the [NET/GROSS] key, and the display value will be changed between gross and net
5. The indicator will display "□OL□" when the scale is overload.

7. 2 Taring

7. 2. 1 Taring an item of unknown weight

To weigh an item in a container, the weight of that container must first be subtracted from the overall weight to obtain an accurate weight reading. This is known as taring.

1. Select the desired weighing unit by pressing the [UNITS] key until that unit is indicated on the display.
2. If necessary, press the [ZERO] key to obtain a weight reading of zero.
3. Place the empty container on the scale's platter and allow the weight indication to stabilize. Then press the [Tare] key to make the NET annunciator on, the display shows zero weight.
4. Place the material to be weighted in the container and allow the weight indication to stabilize. Read the weight shown on the display.
5. You may toggle between the gross weight and the net weight by pressing the [NET/GROSS] key.

7. 2. 3 CLEARING THE TARE WEIGH VALUE

Zero the gross weight and press [TARE] key to zero the tare value.

7. 3 PIECE COUNTING

This mode is used to indicate the number of pieces of an item you have placed on the scale's platform and is accessed by pressing the [UNITS] key. To ensure accuracy, the parts you are counting must be consistent in weight.

The indicator used the sampling method to determine the average piece weight (APW) of the items you wish to count. If the APW of the items is too light or the total weight of the sample is too light, accuracy cannot be guaranteed. You will get an error message, but piece counting will still be allowed.

NOTE: Piece counting must be enabled in the Setup Menu (F12□2) in order to use this feature.

7. 3. 1 PIECE COUNTING – UNKNOWN AVERAGE PIECE WEIGHT

- 1 □ If the items you will be counting require a container, you should first tare off the weight of that container by following the appropriate procedure in either

Section 7.2.1 or Section 7.2.2.

- 2 Select F12 = 2 in Menu F.
- 3 Place the sample items on the platform all at once and allow the weight indication to stabilize. Press the [SET] key, the APW of the items will be displayed if the total weight of the sample is sufficient. Otherwise, the indicator will display Error Code “EE61”, repeat Step 2 to increment the sample size.
- 4 Press the [UNITS] key until the units annunciator off, the indicator now displays “XX 0” and enter piece counting mode.
- 5 Press the [NET/GROSS] key to change the number of the sample “XX” (can be select from 10/20/50/100/200) until displaying the number you want.
- 6 Put XX pieces samples in the plate to display “XX -”.
- 7 Press the [NET/GROSS] key to display “SET” sign, and enter number displaying mode after 1 second, display “YY”.
- 8 Press the [TARE] key to exit number displaying mode, display “XX -”, you can take away the samples and enter step 6.

7.4 PEAK HOLD

Set F12 = 3 so as that the indicator have the peak hold feature, and set the value of peak hold “A13”.

1. Press the [NET/GROSS] key to make the “GROSS” annunciator on.
2. Press the [UNITS] key; if the display weight is greater than A13, then the display goes up with the weight goes up at this situation. When the weight goes down but still greater than A13 and equal with A13, the display keeps on the maximum. When the weight is less than A13, the display goes down with the weight goes down. There is a “≡” in the display when the weight is greater than A13 or equal with A13.

For example, if you select A13=100kg, when the weight goes up to 300kg, the peak hold is 300kg, when the weight goes down to 200kg, display is still 300kg.

3. Press the [UNITS] key the indicator will display the actually weight.
4. When the indicator is in the Peak Hold mode, press [UNITS] key, the indicator will show the actually weight and it will set the weight to be the new Peak Hold weight.

7.5 OPERATION OF PERCENT MODE

You should set F12=4 to enter percent mode.

The percent weight Displayed weight × 100%, the indicator displays percent.

1. Press the [NET/GROSS] key to make the “gross” annunciator on.

2. Press the [UNITS] key by lighting the “PCS” annunciator, the indicator now displays the percent.
3. Press the [UNITS] key to make the “PCS” annunciator off, the indicator will display the actually weight

7. 6 OPERATING OF THE WEIGHT TESTING

You should set F12=5 to enter weight testing mode, and set upper limit and lower limit. The display shows “L” when the weight is less than “Testing lower limit”, also shows “H” when the weight is more than “Testing upper limit”.

7. 7 OPERATING OF THE PRINTING AUTOMATICALLY

You should set F11=3 and F12=5 to start operating the printing automatically, when the weight is added from the weight lower limit to weight upper limit, the indicator will print automatically when the scale is stable.

7. 8 ENTERING AN ID NUMBER

Set “A5 = 0” so that you can enter an ID number

1. Enter A6 in the menu A, and use the [←] and [→] keys to enter the ID number you want, press the [SET] key and the current ID number now reverts back to the value saved in the User Menu.
2. Press the [PRINT] key, the ID number can be printed.

7. 9 ANIMAL WEIGHING MODE

Set “F12 = 6” so that you can enter animal weighing mode.

1. Press the [UNITS] key at formal weighing mode, then appear “=” on the left means that you are entering animal weighing mode.
2. The weight does not increase after the animal step up to the scale and the scale is stable (stable annunciator is on), besides, the weight must be more than 10%F.S., the indicator will lock the weight, when the animal step down the scale and the weight is less or equal to 50%, the indicator will release the weight and the display will vary along with the weight.
3. Please select motion range (F5) according to actual situation when you use animal weighing mode.
4. Press the [UNITS] key to exit and return to formal weighing mode and display actual weight value.

7□10 Accumulation mode

To use this function, We should set A15□0.

- 1□ Press [PRINT] key, To ensure the total value of the displayed weight stored in total unit, The scale should be:
 - a. Stable b. The display value of the scale is positive c. Scale is not overload
- 2□ Press [TARE] key□The display show the total value. Press [UNITS] key to quit the total

function. If the key is not pressed, five seconds later the indicator will be back to the basic weighing mode.

- 3□ If you need to print the total value, press **[PRINT]**key when the display showing the total value□printer will print the total value.
- 4□ If you want to clear the total value, press**[ZERO]**key when the display showing the total value□the indicator will clear the total value.

8 RS□232 Communication

Wiring please sees in Form 3.

8. 1 Consolidated Controls Demand Mode




Fig. 6

8. 2 Recognized Host Commands

- “P”□ This command is sent to the indicator to print the indicated display. The indicator will not respond if the scale is in motion, positive overload or negative overload.
- “Z”□ This command is sent to the indicator to zero the scale. The indicator will not respond if the scale is in motion, positive overload or negative overload.
- “T”□ This command is sent to the indicator to tare the scale. The indicator will not respond if the scale is in motion, positive overload or negative overload.
- “G”□ This command is sent to the indicator to revert to gross mode. The indicator will not respond if the scale is in motion, positive overload or negative overload.
- “N”□ This command is sent to the indicator to revert to net mode. The indicator will not respond if the scale is in motion, positive overload or negative overload.
- “C”□ This command is sent to the indicator to toggle among the configure units.

9. SPECIFICATIONS

- No-linearity 0.01□FS
- Input Signal 20mV
- Input Sensitivity 0.4uV/d
- A/D Conversion Rate 50 times per second
- Internal Resolution 500,000 Counts
- External Resolution 50,000 Counts
- Setup parameter via menu mode, calibrate numerically.
- Extra Units
 - Counting Mode
- Peak Hold
- Percent Style
- Weight Testing Feature
- Time and Date Print
- RS□232C and RS-485 Serial Communications
- Serial Print Output
- 20mA current loop for remote display output
 - Excitation Voltage $8\pm 0.3V$, $8\times 350\Omega$ load cells
- Environmental
 - Operating Temperature $-10\text{□} \sim 40\text{□}$
 - Humidity 40□ (20~90)%RH
 - No corrosive gas and no strong EMI in use field.
- Mechanical 305mm×203mm×102mm(12"×8"×4")

APPENDIX A: PRINT TICKET MODE

DATE	06/02/2000
TIME	12:36
ID.NO	12345
GROSS	1000 kg
NET	800 kg
TARE	200 kg

Select A4=0 in menu "A"

DATE	06/02/2000
TIME	12:36
ID.NO	12345
	1000 kg

Select A4=1 in menu "A"

APPENDIX B: Unit Convert Chart

	off	t	kg	g	lb	oz	Kn	lb:oz
t			1t=1000kg		1t=2204.58838lb			
kg		1kg=		1kg=	1kg=2.20458838lb		1kg=xxx kn	1kg=

		0.0001t		1000g				1(lb)3.27341408(oz)
g			1g=0.001kg		1g= 0.00220458838lb	1g= 0.035273368oz	1g= 0.001×x.xxxxxkn*	
lb			1lb=0.4536kg			1lb=16oz	1lb=□ 0.4536×x.xxxxxkn	1lb=3(lb)2(oz)
oz			1oz= 0.02835kg	1oz = 28.35g	1oz = 0.0625 lb		1oz= 0.02835×x.xxxxxkn *	

Note: *The conversion rate between kg and Kn is different in different place because of the different gravity, x.xxxxx is the set value of A12

APPENDIX C: DISPLAYED ERROR CODES

CODE	MODE	MEANING / POSSIBLE SOLUTION
□OL□	Normal Operating Mode	Gross Overload. A weight greater than the rated capacity has been applied to the scale. Remove the weight from the platter of try re-calibrating the scale. Otherwise, check for a bad load cell connection or possible load cell damage due to overloading.
EE0	Normal Operating Mode	The code of the “F” menu or the “A” menu varies, re-set the code, the EEPROM may be damage if still appearing EE0.
EE01	All Modes	EEPROM error, change “X25045”
EE02	All Modes	RAM error, change “DS12C887”
EE2	Normal Operating Mode after turning on the indicator	Accumulative zero value □20□FS, indicating that the shift of the scale is much large.
EE20	Normal Operating Mode	Press the [ZERO] key since the zero is □20□FS
EE21	Normal Operating Mode	Press the [Zero] key since the scale is in motion or overload.
EE22	Normal Operating Mode	Press the [ZERO] key since the displayed value is out of zero range
EE3	In menu “F” mode	The divisions are not correct, see Appendix C.
EE30	Span Calibration Mode (F20)	No weights on the platform, put the weights on the platform.
EE31	Span Calibration Mode (F20)	Use small weight to calibrate the large weight.
EE32	All Modes	A/D works normally, check the wirings, if so, change the PCB.
EE4	Time and Date Entry	Time entry or date entry is wrong, re-entry.
EE5	Units Select	Unit selection is wrong, change F9 or F10.
EE50	Units Select	Decimal position selected is wrong

EE60	Counting Mode	APW is less than “2”, add the sample weight.
EE61	Counting Mode	The sample number are too many, and the weight of the samples are too less.
EE7	Set Taring	Tare Weight Value > 80□F.S., re-adjust tare weight value.
	Set “A10”	A10 > 80□F.S., re-adjust A10.
EE70	Set Taring	The scale is in motion, positive overload or negative.
EE8	Kn Entry	Kn < 9.70000, re-entry.

APPENDIX D: Minimum Recommended Span Gain Table

F1 \ F2	1	2	5	10	20	50
500	500	1,000	2,500	5,000	10,000	25,000
1,000	1,000	2,000	5,000	10,000	20,000	50,000
1,500	1,500	3,000	7,500	15,000	30,000	75,000
2,000	2,000	4,000	10,000	20,000	40,000	100,000
2,500	2,500	5,000	12,500	25,000	50,000	125,000
3,000	3,000	6,000	15,000	30,000	60,000	150,000
4,000	4,000	8,000	20,000	40,000	80,000	200,000
5,000	5,000	10,000	25,000	50,000	100,000	250,000
6,000	6,000	12,000	30,000	60,000	120,000	300,000
8,000	8,000	16,000	40,000	80,000	160,000	400,000
10,000	10,000	20,000	50,000	100,000	200,000	500,000
12,000	12,000	24,000				
15,000	15,000	30,000				
20,000	20,000	40,000				
25,000	25,000	50,000				
30,000	30,000	60,000				
40,000	40,000	80,000				
50,000	50,000	100,000				